



Instructions for LPM Manne Guitar Bridge



- A: Top screw
- B: Slot for bridge height adjustment
- C: Bridge stud bolt
- D: Threaded insert
- E: Base screw

To adjust the bridge's height :



The "E" base screw's purpose is to firmly lock the "C" bridge Stud bolt in its position, while the "A" top screw's purpose is to lock the bridge to the "C" bridge stud bolt.

CAUTION:

Do not attempt to lower the "C" bridge stud bolt before being sure that the "E" base screw is recessed enough to allow that. Do not overtighten the "E" base screw or the "A" top screws.